

4 Descriptions of Calibration

The calibration work of each module has three parts:

1. **Capturing the images:** According to the needs of each module, use the appropriate exposure to capture the raw image of the calibration board or scene.
2. **Calculate calibration parameters:** import raw images, calculate calibration parameters, and individual modules can fine-tune some parameters as needed.
3. **Confirm and save the parameters:** according to the standards of each module, judge whether the calibration parameters are correct.

4.1 Capture Raw Images

Refer to the operation steps in Section 3.6.

4.2 BLC Calibration

4.2.1 Basic Principles

Since the sensor has Black Level, it also has a certain output voltage when there is no external light, and the final output of the sensor needs to be subtracted from this value. In order to measure this value, some pixels that are not exposed at all are reserved. By reading the size of these pixel values, the Optical Black Level can be obtained in real time. At this time, the output of the sensor is:

$$\text{Raw} = \text{Sensor Input} - \text{Optical Black Level}$$

In addition, considering the signal-to-noise ratio of the sensor output, a base Pedestal is usually placed on the sensor output, and the output at this time is:

$$\text{Raw} = \text{Sensor Input} - \text{Optical Black Level} - \text{Pedestal}$$

Due to the different sensor configurations, for the BLC module, the final BLC correction value can be obtained by capturing the RAW data in the complete black scene.

The correction value here is mainly affected by **Gain** and **Temperature**, so it needs to be calibrated separately at different ISOs. Since BLC is an offset, other modules need to deduct the offset when calibrating, otherwise the correct calibration parameters cannot be obtained.

RV1106 platform:

In order to retain more dark information during Bayer2D and Bayer3D noise reduction, the BLC module adds Sensor OB configuration, which is the Pedestal mentioned above. Some manufacturers support the configuration in the driver sequence, Some are fixed values, which can

be confirmed by querying the data sheet or the driver code. If it is difficult to confirm the value, you can use the reference value in Section 4.2.4 or the BLC average value of each channel calculated by using Gain=1x.

4.2.2 Raw Image Requirements

1. Cover the lens when capturing, make sure no light enters.
2. Capturing needs to traverse Gain=1x, 2x, 4x, 8x, 16x...Max (if the driver supports the maximum Gain to 40x, then Max=32).
3. The exposure time does not affect the BLC calibration and can be unified to 10ms.

4.2.3 Capture Raw Image

1. Open the **RK Capture Tool**, refer to the instructions in Sections 3.1 and 3.2, connect to the device, select **unknown** (no light) for the light source name, and BLC for the module name.
2. Put the device or module in a no light environment, and use a black cloth, lens cover, etc. to cover the lens tightly.
3. Check **Step** and **2^n** on the **Manual Exposure** page, according to **Gain Range**, configure: Gain Begin=1.0 and Gain End=Max, and ExpTime=0.010.
4. Click **Start Manual Capture** to capture the Raw image in steps of 2 to the Nth power.
5. The captured Raw image will be displayed on the right side, select the image you want to view by switching the drop-down box.




Figure 4-2-3-1

4.2.4 Calibration Procedure




Figure 4-2-4-1 BLC calibration results

1. Open **Calibration Tool**, click **Edit Options** in the upper left of the interface, open the configuration interface, and enter the size, bit width and bayer order of the raw image.
2. Select the **BLC** page, click the **Load Raw Files**, and select a folder to store Raw images.
3. The imported Raw image will be displayed in the list on the right.
4. Click **Calibrate** to start.

RV1106 platform: Linear mode calibration needs to enter the **Sensor OB** value first. We list some commonly used OB values for reference:

Manufacturers	OB value for reference
GalaxyCore(gc)	256
OmniVision(ov/os)	256
Samsung(s5k)	256
SmartSens(sc)	256
Sony(imx)	The driver sequence can be configured, it is recommended to refer to the DataSheet and driver code, whichever is the actual.

5. The Black Level Curve obtained from calibration is displayed on the upper axis.
6. The BLC value obtained from calibration will be in the table, click **Save**.

Notes:

1. If the device itself has power light and status indicators, etc., pay attention to whether there is light leakage.
2. An incorrect BLC value will affect the calibration results of all subsequent modules. Please make sure that the BLC results are correct before performing subsequent calibration.

4.3 LSC Calibration

4.3.1 Basic Principles

Luma Shading is caused by the optical properties of the lens. For the entire lens, think of it as a convex lens. Since the light-gathering ability of the center of the convex lens is much greater than that of its corner, the light intensity in the center of the Sensor is greater than that in the corner areas. For an undistorted camera, the illumination attenuation around the image follows the formula:

$$\cos^4 \theta$$

4.3.2 Raw Image Requirements

1. When capturing, cover the lens with diffuser (or use DNP light box, integrating sphere and other equipment).
2. Capture in a light box with standard lighting, we recommend to calibrate 7 light sources: HZ, A, CWF, TL84, D50, D65, D75.
3. To prevent the AC light source from generating Flicker, it is recommended to use an integer multiple of 10ms to configure the exposure time.
4. The maximum brightness of the Raw image is about 200 (8bit), and the minimum brightness should be significantly larger than the black level value calibrated in the previous section.
5. We recommend to use the diffuser as shown below:




Figure 4-3-2-1 Opal Diffuser

4.3.3 Capture Raw Image

1. Open the **RK Capture Tool**, refer to the instructions in sections 3.1 and 3.2, connect to the device, and select **LSC** as module name.
2. Put the module in the light box, switch to **HZ** light, and place the diffuser close to the lens.

3. Select **HZ** light source, check **Search Exposure by Max Luma (8bit)** on the **Auto Exposure** page, check **Anti Flicker (50hz)**, and configure the maximum brightness of the target over the right to **200±10%, Frame Number = 1**.
4. Click **Start Auto Capture** to capture a raw image, during which the tool will automatically select the appropriate exposure until it meet the preset maximum brightness.
5. Switch the light source to **A**, change the name of the light source to **A**, and repeat step 4 until all light sources are finished.

Raw Capture Online Capture

Sensor: **sc4336** Light: **HZ** Module: **LSC**

Width: 2560 Height: 1440 Bits: 10

Gain Range: 1.0 - 480.0

Exp Range: 0.0001 - 0.100

VCM: 64

Conversion Gain Mode: ☒ Normal ☐ LCG ☐ HCG

Manual Exposure Auto Exposure YNR Capture

☒ Search Exposure By Max Luma(8bit) 200 ± 10 %

☐ Search Exposure By Mean Luma 80 ± 5 %

☒ Anti-Flicker(50Hz) ☐ Anti Flicker(60Hz)

Frame Number: 1

☐ Multi-Frame ☐ Low-Light ☐ High-Light **Start Auto Capture**

Figure 4-3-3-1

4.3.4 Calibration Procedure

1. Open **Calibration Tool**, click the **Edit Options** in the upper left corner, open the configuration interface, and enter the size, bit width and bayer order of the raw image.
2. Select the **LSC** and click the **Load Raw Files** to import all raw images.
3. The imported raw image will be displayed in the above window.
4. Modify the **Light Fall off** to 100%.
5. Click **Calibrate** to start.
6. After calibration is done, we can view the raw image of each light source on the **result** page.
7. Click Save.
8. Modify the **Light Fall off** to 70%, repeat steps 5~7.




Figure 4-3-4-1




Figure 4-3-4-2

Notes:

The tool may not be able to find suitable exposure parameters because the light is too bright or too dark. In this case, we can refer to the following solutions:

1. Adjust the brightness of the light source.
2. Use ND filter.

3. Adjust the lens orientation.
4. Modify the Gain Range or Exp Range.
5. Adjust the maximum brightness or threshold value for automatic exposure.
6. Use manual exposure instead (the minimum standard for selection is that the minimum brightness is significantly greater than the Black Level value calibrated in the previous section).

4.4 AWB Calibration

4.4.1 Introduction

Calibrate the white point conditions of raw in XY, UV, YUV, the simple color algorithm parameter and the white balance gain under standard light source.

4.4.2 Raw Image Requirements

Preparations for capturing raw images:

1. Equipment: X-Rite 24 ColorChecker, Light Box (including D75, D65, D50, TL84, CWF, A, HZ)
2. Adjust the exposure parameters, so that the maximum value of the brightest white block in the color is [150-240], the brighter the better within this range (if you want to use the same raw image with the following CCM, it should be darker)
3. The ColorChecker occupies more than 1/9 of the screen

Raw image capturing method:

1. Open the **RK Capture Tool**, refer to chapter 3.1 and 3.2, connect to the device, module selects to **CCM_AWB**.
2. Put the device and the ColorChecker in the light box, adjust their position, make the ColorChecker in the center of the screen, capture as large as possible, and do not move the device
3. Open the light box and switch the light source to **HZ light**.
4. Select **HZ**, check **Search Exposure By Max Luma (8bit)** on the **Auto Exposure** page, check Anti Flicker (50hz), and configure the maximum brightness of the target on the right to $200 \pm 10\%$, Frame Number = 1.
(If at 1x Gain, 10ms integer multiples cannot capture raw images, turn off **Anti-Flicker (50hz)** and try again)

Raw Capture Online Capture

Sensor: Light: Module:

Width: Height: Bits:

Gain Range: -

Exp Range: -

VCM:

Conversion Gain Mode: ☒ Normal ☐ LCG ☐ HCG

Manual Exposure Auto Exposure YNR Capture

☒ Search Exposure By Max Luma(8bit) ± %

☐ Search Exposure By Mean Luma ± %

☒ Anti-Flicker(50Hz) ☐ Anti Flicker(60Hz)

Frame Number:

☐ Multi-Frame ☐ Low-Light ☐ High-Light

Figure 4-4-2-1

- Click **Start Auto Capture**, the tool will automatically select the appropriate exposure until the preset maximum brightness is reached.
- Switch the light source to **A**, name the light source to **A**, and repeat the previous steps until all light sources are finished.

For example, the calibration raw image after demosaicing are as follows:




Figure 4-4-2-2

4.4.3 Calibration Tool Introduction

1. Adjust the white point condition of the UV and XY domains, and the TH value of the YUV domain.




Figure 4-4-3-1




Figure 4-4-3-2

2. Instructions for adjusting white point conditions in the UV and XY domains
 - a) Use the mouse to drag the four corners of the white point area of any light source in the coordinate system to adjust the position and size
 - b) Drag the mouse in the blank area in the coordinate system to adjust the display range.
 - c) Use the scroll wheel to zoom in and out to adjust the scale.
 - d) The **Exclude WPC Range** parameter can set the non-white point area and the extra light source white point area.
3. Click the "AWB Simulation" button, this function can be used to detect the white point of the original image, calculate the WB Gain and the number of white points, and map the specified pixels to the UV and XY domains to confirm the correct white point conditions.

AWB Simulation

Preview

Image

Load Image

Run Simulator

Stats of Point Track

Pos: 0,0

R:

G:

B:

Y:

U:

V:

X:

Y:

RGain:

BGain:

Light

U_Interp

Th_Interp

Distance

Stats Result

☒ All

WP Number

RGain

BGain

☒ A

☒ CWF

☒ D50

☒ D65

☒ D75

☒ HZ

☒ TL84

Figure 4-4-3-3

a) After clicking LoadImage to import the raw image, as shown below, the white point information will be printed. The white points of different light sources are displayed in different colors. The number of white points in the middle frame and large frame, RGain accumulation and BGain accumulation will be displayed in the three text boxes of WP Number, RGain and BGain




Figure 4-4-3-4

b) Click any position in the image (the black arrow as shown below), it will be mapped to the UV domain axes and the XY domain (small black square), which is convenient to check whether the point falls in the white point range. At the same time, the R G B U V X Y RGain BGain (red frame area) of the point is displayed, and the u and th after the point is mapped to each light source in the yuv domain and the deviation distance from the standard white point (corresponding to the three columns in the green frame area)




Figure 4-4-3-5




Figure 4-4-3-6

4.4.4 Calibration Procedure

1. Open **Calibration Tool**, click **Edit Options** to open the configuration window, and enter the size, sensor bpp and bayer order of the raw image.
2. Before AWB calibration, we must complete the BLC and LSC calibration.
3. Click **Load Raw Files** to import the raw images of A, CWF, D50, D65, D75, HZ, TL84 (we recommend these seven light sources).
4. Click **Find Chart** to open the color block search GUI. If the imported image is mirrored, it can be flipped through the **Flip function** area on the right. The current version supports horizontal and vertical flips.




Figure 4-4-4-1

- a) Adjust the statistics area by dragging the red frame center dots on the upper left, upper right, lower left and lower right, and try to ensure that the statistics area is in the center of each color block, as shown in Figure 4-4-4-1
- b) Click FindChart to identify the color blocks of all light sources, as shown in Figure 4-4-4-2




Figure 4-4-4-2

c) Select another light source from the menu to confirm that the color patch detection results are correct. If the detection is correct, as shown in Figure 4-4-4-4. If it is found that the position of the detection result is wrong, as shown in Figure 4-4-4-3, it is only necessary to re-detect it separately. Select “Find Current Chart” in Mode and repeat steps a) and b) until the detection result is correct.




Figure 4-4-4-3




Figure 4-4-4-4

d) Click the save button to complete the detection

- Click **Calibrate** to start. It will take about 30s. the following initial white point conditions and other parameters are obtained. Those dots in different colors in the coordinate systems of the UV and XY domains represent the positions of the color block values in the ColorChecker captured by each light source in the UV and XY color spaces, the rectangle box represents the white point conditions of different light sources.




Figure 4-4-4-5

WFC (UV Domain & XY Domain)		WFC (YUV Domain)				
Light Names	U0	U1	U2	U3	U4	U5
A	50	54	70	78	110	142
CWF	50	54	70	78	110	142
D50	50	54	70	78	110	142
D65	50	54	70	78	110	142
D75	50	54	70	78	110	142
HZ	50	54	70	78	110	142
TL84	50	54	70	78	110	142
Light Names	Th0	Th1	Th2	Th3	Th4	Th5
A	0.2	0.2	0.2	0.76	1	4
CWF	0.2	0.2	0.2	0.76	1	4
D50	0.2	0.2	0.2	0.76	1	4
D65	0.2	0.2	0.2	0.76	1	4
D75	0.2	0.2	0.2	0.76	1	4
HZ	0.2	0.2	0.2	0.76	1	4
TL84	0.2	0.2	0.2	0.76	1	4


Figure 4-4-4-6

- Click **AWB Simulation** and import the raw images of A, CWF, D50, D65, D75, HZ, TL84 in turn to check the accuracy of white point detection.
- Modify the frame of the UV domain or the XY domain or the TH of the YUV to make the white point detection of the ColorChecker under each light source more accurate.
- Click **Save**, and click **Run Simulator** on the **AWB Simulation** interface to view the white point detection results of the imported light source image.
- Repeat steps 6 to 8 until the white point detection of each light source is reasonable.


Notes:

1. Adjust the condition, try best to make white points (points marked 19, 20, 21, and 22 blocks) inside the box, and the non-white points are outside the box.
2. The middle box of all light sources on the blackbody locus is continuous in the x direction.

Example of error as shown in the below: Small spacing between large boxes, but large spacing between middle boxes




The correct example is as follows:




3. A and HZ light sources can be slightly smaller in the Y direction of the XY domain, and D50 and D65 can be slightly larger in the Y direction of the XY domain.
4. Two light sources with very close color temperature (CWF and TL84) can be changed to be adjacent in the Y direction.
5. In the UV domain, there cannot be a gap between any two light sources.
6. The areas of different light sources can overlap, but do not overlap in both the XY and UV domains at the same time.
7. When excluding non-white points, adjust the UV domain with the distribution of the XY domain as a reference.

For example, the 7th block of D75 circled in the picture below falls within the HZ range and will be incorrectly detected as a white point.



After readjustment, the 7th block of D75 light source is not in the same light source in xy and uv space and will not be recognized as a white point.



8. When the non-white point falls in the white point range of XY and UV, it can also be excluded by reducing TH, or by increasing the non-white point range.
9. When the white point falls within the white point range of XY and UV, but it is still not a white point, it may be excluded because it exceeds the brightness range, or it falls within the non-white point range, or it is less than TH and does not fall within the white point range. In the white point interval of the YUV domain.

4.4.5 Example of AWB Calibration Results

Final White Point Conditions:




Figure 4-4-5-1

The white point detection results of each light source are:




Figure 4-4-5-1 A




Figure 4-4-5-2 CWF




Figure 4-4-5-3 D50




Figure 4-4-5-4 D65




Figure 4-4-5-5 D75




Figure 4-4-5-6 HZ




Figure 4-4-5-7 TL84

4.5 CCM Calibration

4.5.1 Raw Image Requirements

The raw image requirements refer to chapter 4.4, CCM can use the raw image of AWB to calibration.

In addition, since the Gamma curve will affect the CCM results, it may be necessary to adjust the CCM parameters again when the Gamma curve is modified. In this case, please refer to chapter 4.5.2, point 12.

4.5.2 CCM Calibration Procedure

1. Open the **Calibration Tool**, select the **CCM**, and click the **Load Raw Files** to import all raw images. The imported raw image will be displayed in the list:




Figure 4-5-2-1

- Click Find Chart to open the color block search GUI.




Figure 4-5-2-2

- Drag the red frame center dots on the upper left, upper right, lower left, and lower right to adjust the sampling area, and make sure that the sampling area is in the center of each color block.
- Click **Find Chart** to start counting the color block values, and the statistical area will be marked in green.
- Check each light source in the list and confirm whether the statistical area is correct.




Figure 4-5-2-3

- After the search is complete, click **Save** and then exit.
- Set the saturation to 100%, as shown in Figure 4-5-2-4.




Figure 4-5-2-4

8. Click the **Calibrate** to start the calibration. It takes about 20s.
9. After the calibration is completed, the calculation result will be on the **result** page.
10. Click the **Save** button.
11. Modify the saturation to 74% and repeat steps 8~10.




Figure 4-5-2-5

12. If ΔE is too large, the raw image may be too bright. You can right-click the ColorChecker image on the right side of Figure 4-5-2-5, click Save Current, save the image, and check whether each color patch is overexposed or a certain channel is saturated (CCM calibration after applying the Gamma curve may cause calibration patches saturation).
 - a) If there is a problem of over-brightness or over-saturation, you should re-capture the color chart of the light source, reduce the exposure, and re-calibrate.
 - b) If the brightness of the color blocks is normal, the possible causes of the problem are: abnormal BLC parameters, abnormal LSC parameters, lens light leakage (infrared light), etc..
13. For specific tuning methods, please refer to **Rockchip_Color_Optimization_Guide**

4.6 NR Calibration

4.6.1 Raw Image Requirements

NR module raw image capture instructions:

1. Capture in a light box with a standard light source, it is recommended to use a DC light source with adjustable brightness.
2. A grayscale gradient card must be used, as shown in Figure 4-6-1-1.




Figure 4-6-1-1

3. Exposure needs to traverse Gain=1x, 2x, 4x, 8x, 16x...Max (for example, if the maximum gain is supported to 40x, then Max=32).
4. Four Raw images need to be captured under each Gain, namely highlight-stacked frame, highlight-single frame, low-light-stacked frame, and low-light single frame.
5. High light and low light can be distinguished by adjusting the exposure time or light brightness, and multiple frames and single frames are generated by tool processing.
6. The following brightness values are all 8-bits.
7. Low-light image requirements: the pixel value of the brightest block in Figure 4-6-1-1 reaches 30 (to ensure that the boundary of each color block can be seen clearly, if it is not satisfied, it can be appropriately increased), and the pixel value of the darkest block reaches Black-Level (It can be satisfied when the pixel value of the brightest block just reaches 30).
8. Highlight image requirements: the pixel value of the brightest block in Figure 4-6-1-1 reaches 255, and the pixel value of the darkest block is generally around 60-70.
9. RK Capture Tool provides the YNR Capture function, which can automatically search for qualified exposure combinations based on the brightness of the darkest and brightest blocks settings.

4.6.2 Capture Raw Image

1. Open the **RK Capture Tool**, refer to the instructions in sections 3.1 and 3.2 to connect the device.
2. Put the device or module in the light box, and stick the gradient chart on the light box.
3. Adjust the position of the device so that the gradient chart is moved to the center of the screen, and it is as close to the picture as possible.

4. Turn on the light box and switch the light source to TL84 or CWF.
5. Modify the light source name to TL84 or CWF, and the module name to NR_Normal.
6. Assuming that the sensor supports Gain=1-24, we need to capture 1x 2x 4x 8x 16x.
7. Select the **YNR Capture**, first take a raw image, right-click on the preview on the right and select **Draw ROI**, and select the brightest block and the darkest block in the preview image in turn (represented by black and white blocks later), double-click the rectangle, we can re-draw it, fix the image position and the rectangle position, and perform NR capturing, as shown in Figure 4-6-2-1.




Figure 4-6-2-1

8. Capturing the low-light raw image:

The brightness of the light box is adjusted to about 800lux.

Modify the value of Gain Range in the tool to 1.0 - 1.0, and Exp Range will not be modified.

Check Multi-Frame and Low-Light.

Select the YNR Capture page and fill in the thresholds of the black and white rectangles.

set FrameNumber=32.

Black Block Mean Luma: The target value to be achieved by the black block, which is initially filled in as $BLC(8bit)+1$.

White Block Mean Luma: The target value to be achieved by the white block, the initial fill is 30.




Figure 4-6-2-2

- Click the Start YNR Capture button to start capturing, and the current average pixel value of the two rectangular boxes and the corresponding exposure parameters will be printed in the log box; meanValue[0]: the current average pixel value of the black block; meanValue[1]: The current average pixel value of the white block; blackTarget: the filled Black Block Mean Luma threshold; whiteTarget: the filled White Block Mean Luma threshold.
- When the threshold value cannot capture the image, as shown in Figure 4-6-2-3, check the log, find that meanValue[1] is just larger than the meanValue[0] of whiteTarget, and set this value to Black Block Mean Luma (In order to avoid noise interference threshold, meanValue[0] can be slightly increased), as shown in Figure 4-6-2-4.




Figure 4-6-2-3




Figure 4-6-2-4

- c) After finding the threshold that satisfies the conditions, click the Start YNR Capture button again to start the capture. After the capture is completed, one Raw image with the Multiple and Single suffixes is obtained, as shown in Figure 4-6-2-5.




Figure 4-6-2-5

9. Capturing the high-light raw image:

The brightness of the light box is adjusted to about 800lux.

Modify the value of Gain Range in the interface to 1.0 - 1.0, and Exp Range will not be modified.

Check Multi-Frame and High-Light.

Select the YNR Capture page and fill in the following two boxes for the thresholds.

Black Block Mean Luma: Indicates the target value to be achieved by the darkest block, the initial fill is 60.

White Block Mean Luma: Indicates the target value to be achieved by the brightest block, fixed at 255.

set FrameNumber=32




Figure 4-6-2-6

- Click the Start YNR Capture button to start capturing, and the log of the tool will print the average value of the ROI area, exposure and gain after each exposure adjustment.
 meanValue[0]: the current average pixel value of the darkest block.
 meanValue[1]: the current average pixel value of the brightest block.
 blackTarget: the filled Black Block Mean Luma threshold.
 whiteTarget: the filled White Block Mean Luma threshold.
- When the exposure and gain reach the maximum, but the brightness of the brightest block still cannot reach 255, as shown in Figure 4-6-2-7, you need to manually adjust the brightness of the light box, and then click Start YNR Capture to re-capture, after the conditions are met Obtain a Raw image with Multiple and Single suffixes, as shown in Figure 4-6-2-8.




Figure 4-6-2-7




Figure 4-6-2-8

10. Modify the **Gain Range** value to 2x, and repeat steps 8 and 9 until all Gain capturing is completed.

11. Since the **Gain** will continue to increase, the threshold of the black block will be greatly affected by the noise, and the threshold of the black block can be slightly adjusted according to the printed log.

4.6.3 Calibration Procedure

GIC & BayerNR and YNR & MFNR modules share the same set of Raw images:

1. Open **Calibration Tool**, click the **Edit Options** button in the upper left corner, enter the size, bit width and bayer order of the Raw image.
2. Select the **GIC & Bayer NR** page, click the **Load Raw Files** button to import all Raw images, and the imported Raw images will be in the list below.
3. Click **Find ROI** to frame the position of the gradient chart, as shown in Figure 4-6-3-1, make sure that the rectangular frame is within the color block.




Figure 4-6-3-1

4. Click **Calibrate** button to start.
5. The **BayerNR** noise curve obtained after the calibration is completed will be displayed in the right window, as shown in Figure 4-6-3-2.




Figure 4-6-3-2

6. Click **Save**.
7. Select the **YNR&MFNR** page, click the **Load Raw Files** button to import all Raw images, and the imported Raw can be found in the list below.
8. Click the **Calculate YUV** button, the Raw image will be processed into a YUV image by the simulator.
9. Click the **Calibrate** button, and check **YNRCurve Print** before Calibrating to save the calibration parameters and sampling points of each iso.
10. The YNR noise curve obtained from calibration will be in the right window, as shown in Figure 4-6-3-3.
11. Click **Save**.




Figure 4-6-3-3

Notes:

If the generated noise curve is very different from the curve in Figure 4-6-3-3, it may be that the high light or low light brightness is wrong. You can judge according to the abnormal position of the curve:

The wrong curve on the left means that the low light brightness is not suitable.

The wrong curve on the right means that the highlight brightness is not suitable.

The color temperature of the light source used should not be too high or too low, otherwise the result of Calculate YUV may be incorrect.

If the minimum brightness of the light box cannot meet the capturing requirements, you can use a light reduction film to assist the capture.

4.7 FEC/LDCH

To use the **FEC/LDCH** module, a **map** table is needed. The map table only with the coordinates of the horizontal x/y direction of the image, and is a mapping table after down-sampling. To get the map table, we need to know the relevant parameters of the camera lens. We need to capture a set of checkerboard images, and then use the calibration tool to calibrate.

4.7.1 Calibration Image Requirements

Capturing checkerboard, the checkerboard size is changeable, and the calibration image only supports jpg, bmp, png format.

Checkerboard capturing has two modes:

Method 1: One image contains only one checkerboard (higher precision, recommended).

Method 2: One image contains n checkerboards (for the convenience of calibration, n=4).

1. Preparations

(1) The checkerboard should be a standard calibration board. If you print the checkerboard by yourself, please pay attention to the real size. The self-printed checkerboard should have a flat surface, preferably fixed on a flat board. The number of checkerboards grids should be different from the horizontal and vertical grids as much as possible, which is convenient for the calibration tool to identify the direction.

(2) Appropriate lighting conditions and capturing environment: The lighting is moderate to ensure that the images from all angles during the capturing process are clear, and there should be no reflection or blur on the checkerboard. In the whole process, the aperture and focal length of the camera should be fixed, and it is necessary that the amount of light entering the camera and the focal length are fixed.

2. Operating rules

(1) Appropriate ratio: try to make the captured checkerboard image occupy between 1/4 and 1/8 of the entire camera field of view.

(2) Appropriate number: make sure that the checkerboards of all images can cover the entire camera field of view, the number is usually about 15, too few quantities will cause inaccurate calibration parameters. It is recommended to take 3-4 pictures at the same position, In order to facilitate subsequent screening and replacement of unqualified images.

(3) Appropriate distribution: As shown in Figure 2-1, make sure that the captured images of the calibration board are evenly distributed in all areas and corners of the camera's field of view, and when it is close to the edge of the field of view, the checkerboard should be as close to the edges as possible, **but take care that do not make the checkerboard out of the image field of view.**

(4) Different tilt angles: We should not just capture images parallel to the plane of the lens, but make sure it with different tilt angles.

3. Capturing demonstration

There are two ways to capture:

(1) Method 1 (recommended)

Four calibration pictures, the checkerboard occupies four positions of the upper left, upper right, lower left and lower right in the calibration picture, and there is no specific order.






Figure 4-7-1-1

(2) Method 2

A calibration image, the upper left, upper right, lower left and lower right corners are covered with checkerboards.



Figure 4-7-1-2

4.7.2 Calibration Procedure




Figure 4-7-2-1

1. Configure the resolution in the **Raw Options**. Bit and Bayer Pattern can be ignored.
2. Import the folder of calibration images. Support jpg, bmp, png formats.
3. Adjust the calibration configuration parameters.
 - a) **Square Size**: The actual size of each grid in the checkerboard, generally 30mm or 25mm.
 - b) **Horizontal/Vertical**: The number of inner corner points of the horizontal (Horizontal) and vertical (Vertical) of the checkerboard:
 - c) **Check Board Number**: the number of checkerboards in each image can be 1 or 4.
 - d) **Level**: Set the Level of distortion correction, which is divided into 256 levels. Level = 0 means that the mapping table obtained at this time has no correction effect (that is, the output image is the same as the input image), and Level = 255 means that the mapping table is the maximum degree of correction that LDCH can achieve.
 - e) **Correct Direction**: If the mapping table is generated for the FEC module, we can also set different corrections:
 - i. Only check Correct X: Only correct the horizontal direction, the effect is similar to LDCH.
 - ii. Only check Correct Y: only the vertical direction is corrected.
 - iii. Both Correct X and Correct Y: both horizontal and vertical directions are corrected.
4. Click Calibrate.
5. Save the results.

How to distinguish the corners and interior corners of the checkerboard (see Figure 4-7-2-2). The picture below shows a checkerboard with 12 horizontal and 9 vertical grids. The number of horizontal corners is 13, the number of horizontal inner corners is 11, and so on. So Horizontal = 11, Vertical = 8.




Figure 4-7-2-2 The corners and interior corners of the checkerboard
(Corners include red and green parts, while inner corners only include red parts)

Notes:

1. Check the "result" folder exists in the toolpath, if not, we have to create a new folder called "result" and place it in the same directory as the Calibration Tool.
2. The outermost circle of the chessboard is indeed calculated. However, when capturing the image, the black and white blocks in the outermost circle cannot be completely blocked by the preview.
3. The number of corner points in the horizontal direction is equal to: the number of black and white blocks in the horizontal direction **minus 1**.
4. The number of corner points in the vertical direction is equal to: the number of black and white blocks in the vertical direction **minus 1**.
5. FEC is corrected in both directions by default. When calibrating, the direction can be selected.
6. The folder for storing the image, preferably named after sensor name + lens name/focal length + resolution, the tool will generate a folder for storing calibration files according to this name

4.7.3 Example of Calibration Results

1. If there is an unsuccessful calibration result, generally, the corner detection is inaccurate or incomplete due to the unclear capturing of the checkerboard. Therefore, we should first check whether the corners of each image checkerboard are completely and accurately detected, and the number of complete detections cannot be less than 3.
2. If the calibration is successful, the result shown in Figure 4-7-3-1 will appear. We can view the calibrated distortion parameters in the “log” on the left. The meanings of the six parameters from top to bottom are: the center coordinates of the camera (cx, cy), camera distortion parameters (a0, a2, a3, a4).
3. On the “**result**”, we can view the checkerboard corner detection results for each image. If the detection result is inaccurate, delete the image, and re-calibrate it to obtain a more accurate result. The generated FEC and LDCH mapping table is stored in the corresponding folder under the “**result**”.




Figure 4-7-3-1